

Sensory Robotics - depth camera

Image segmentation with depth image

Goals:

With the help of Intel RealSense d435i camera system: segmentation of RGB images on the basis of their appropriate depth image-pairs.

Short description of the exercise:

Software environment: Python

Tools to use during this lab:

- Intel RealSense d435i camera system.

There are multiple ways how depth cameras can work (even in the laboratory we have more types of them). For a good comprehension of the types, please read the following post carefully:

<https://www.intelrealsense.com/beginners-guide-to-depth/>

The system is capable of registering/creating an RGB and a depth image, see Fig. 1.




Figure 1: visualized sample images, captured simultaneously.

Description of the measurement:

During the measurement, you have to produce two pairs of images:

- in one RGB+depth pair: it should capture an empty scene, in the further away third: one of you should stand,
- in the other RGB+depth pair: the same empty scene, but with a chair in the center/closer region of the image.

The task: combine the two RGB images on the basis of their corresponding depth images, in the way that the chair should hide a part of the standing person.

Exemplary image-pairs can be seen in Fig. 2 (with two different chairs).




Figure 2: exemplary image-pairs.

The result of the simplest image fusing can be seen in Fig. 3 – *please do a more elaborated solution!*




Figure 3: the result of the simplest image fusing – you can observe multiple errors in the resulted image.

Available source-codes:

Already given:

- **modified_align_depth2color.py**: a script initializing the camera, and showing the RGB and depth streams continuously. Please carefully read and understand what is inside this code. Feel free to ask any question. Pressing key 'c' you can record the current RGB+depth pair of images as **.npz** arrays.

Please prepare:

- a script: this loads your saved **.npz** archives, shows the raw images, then fuses them, finally showing also the fused result.

What and when to upload:

What:

- all of your modified/new source codes,
- all of your **.npz** files,
- your report.

Please include in the report your opinion about the measurement errors seen in the image, please try to make a more 'noise-less' combination (with standard image processing routines).

Deadline: indicated in moodle.

Thank you.

Miklós